



Ref: TT0003
V1.3




CMS - Screen / Menu Lock on Select Monitors

Related Products - Non-AHD Select (VBV) range of monitors.

All Brigade monitors come with the option of locking and unlocking the menu / buttons.

For the non-AHD Select (VBV) range of monitors holding the Menu button  for 20 seconds will lock or unlock the On-screen Display. The word **LOCKED** or **UNLOCKED** will display on the screen for 2 seconds.



Once in the **Main Menu** use the Up  or Down  buttons, then use the Select button  to access the **Advance Menu**. Do the same to select **Menu Lock** and to change the Levels.



Level 1 – Locks all buttons: On/Off, Select, Menu, Up and Down.



Level 2 – Locks just Select and Menu buttons. The power and Up & Down buttons are still available.

Level 3 – Locks just the **Main Menu**. Only the **Display Menu** is available.

