



Ref: TT0016
V1.2

CMS - Select Monitor Image View – Normal/Mirror




Related Products - All non-AHD Select (VBV) range of monitors. (Not Brigade Van or Essential models).

Brigade non-AHD Select (VBV) range of monitors have the option to change the camera image from Normal to Mirror view, and vice versa.




The Screen / Menu must be unlocked to access the menus below.

To change the image view, hold the **Menu Button**  for approximately 2 to 3 seconds, until the **Main Menu** appears. Using the **Select Button**  select **Camera Settings**.




When in **Camera Settings** menu select the camera number that requires changing by using the Up  or Down  buttons, then press the **Select Button** .



Once in the **Camera** menu select  **Nor/Mir**, this will change the text to green. Use the Up  or Down  buttons to change from **Normal** or **Mirror**.



Press the **Menu Button**  three times to exit the menu screens, or leave for approximately 10 seconds for it to revert back automatically.

These settings assume a normal view camera is fitted. If a mirror view camera is installed the views would be reversed.

Where to find this and other Tech Tips on the website

