



#### Ultrasonic Obstacle Detection



\*For more information on the correct sensor height and angles please refer to the Tech Tips UDS Fixing Height & Angles Explained on the website – [click here](#)

\*\*For more information on activating ELM please refer to the Tech Tips UDS ELM on the website – [click here](#)

\*\*\* When the movement in the steering angle is enough that the wheel(s) protrude from the bodywork

**Title:** UDS False Detection  
**Reference Number:** DW0004  
**Version:** 1.0  
**Product:** BS-4000W (3744), CS-3000 (3712), CS-3100 (5261), FS-4000W (3747), SS-4000W (3711), SS-4100W (5257), SS-4200W (5916), ST-2000 (3742) & ST-2100 (5262)